

- Q: Can I use this unit without the cord?
- A: Yes. The **Emjoi® Divine** can be used without the adapter cord once it has been charged.
- Q: Do I have to clean the **Emjoi® Divine**?
- A: Yes. We recommend that you clean your unit after each use. Before cleaning make sure to turn off your unit and if it is plugged in, unplug it from the electrical outlet. Remove the disc cover of the unit by squeezing both sides of the disc cover. Using the brush, enclosed, remove hair on all sides of the discs. Replace the disc cover by gently pressing until it clicks into place.
- Q: Should I let someone else use my **Emjoi® Divine**?
- A: No. For sanitary reasons, the **Emjoi® Divine** is only recommended to be used by one person.

Shaving Questions

(Optional Attachment)

- Q: When should I use the shaving attachment?
- A: The shaving attachment is available so you can have the ultimate hair removal experience. You can epilate, for long lasting results or shave; it is totally up to you.
- Q: How do I change from the epilation head to the shaving head?
- A: Make sure that your **Emjoi® Divine** is in the "Off" position. Press the release button on the front of the unit and gently pull off the epilation head. Place the shaving attachment into the unit by pressing until it clicks into place.
- Note:** When placing the shaving attachment into the unit, make sure that the toothed wheel on the unit and the opening of the shaving attachment line up.
- Q: What is the comb coming out of each side of the shaving attachment?
- A: That is a long hair trimmer to make shaving even more effective than the foil head alone.
- Q: How do I clean the shaving attachment?
- A: It is recommended to clean the shaving attachment after each use. Use the cleaning brush, enclosed, to gently brush the hairs off the unit.

Exfoliation Questions

(Optional Attachment)

- Q: When should I use the exfoliation attachment?
- A: The exfoliation attachment is available so you can have the ultimate smooth skin experience. You exfoliate to soften rough skin and epilate to remove hair for silky skin all over your body.
- Q: How do I change the epilation head to the exfoliation head?
- A: Make sure that your **Emjoi® Divine** is in the "Off" position. Press the release button on the front of the unit and gently pull off the epilation head. Place the exfoliation attachment into the unit by pressing until it clicks into place.

Emjoi® Divine

Before using your Emjoi® Divine, please read all these instructions carefully and completely.

The **Emjoi® Divine** is a terrific hair remover with 36 tweezer action discs to ensure rapid, non-irritating and virtually painless hair removal from the root. With its glide technology and massaging finger attachment removing hair from the root has never been easier or more comfortable. The **Emjoi® Divine** removes hair as short as 0.5 mm on the face, legs, bikini line and underarms leaving skin super smooth for up to 6 weeks.

When using an epilator for the first time we suggest that you test the unit on an area that has light hair growth in order to get accustomed to the epilation process.

Caution

Do not store or use your **Emjoi® Divine** where it can fall into a tub or sink of water. Do not reach for your unit if it has fallen into water, immediately unplug it.

Note: The **Emjoi® Divine** is a rechargeable hair remover that can be used as a rechargeable device without the cord or with the cord by connecting it to an electrical outlet. Your unit cannot be turned ON if the cord is plugged into the unit but not into the electrical outlet. Before using the **Emjoi® Divine** for the first time as a rechargeable device, it should be charged for, at least, 16 hours. It is recommended that you recharge your unit for 8-16 hours after each use so your unit is always charged when you need it. To preserve and extend the life of the battery it is recommended to occasionally discharge the battery, let the charge run out completely, and then recharge it.

Caution

Before plugging into an electrical outlet, make sure that the adapter is appropriate for the local voltage. This is extremely important when travelling overseas.

Instructions for use

For best results: Take a warm bath or shower, to open up your pores, and use a loofa or exfoliation cream in small circles to exfoliate and remove dead skin from the area you wish to remove hair. Doing this before you use your **Emjoi® Divine** will cleanse and make your skin pliable, so removing hair will be less uncomfortable.


1. Use your **Emjoi® Divine** in a location that has a comfortable temperature to avoid perspiration.
2. Make sure that the areas you wish to remove hair from are clean, dry and free from moisturizing cream or oil.
3. After your unit is charged remove the adapter plug from the bottom of the unit. If your unit is not charged, insert the adapter plug into the bottom of the unit and plug your adapter into an electrical outlet.
4. Remove the protective cap, by gently pulling, from your **Emjoi® Divine**.
5. To turn On your unit, press the safety switch lock and at the same time slide it up to the desired speed. Low is recommended for fine hair and high is recommended for coarse hair.
0 Power "OFF"
1 Low speed
2 High speed
6. Hold the unit in your palm, at a 90° angle, so the Emjoi® logo is facing you.
7. Position your **Emjoi® Divine** so that the discs are upright, the Emjoi® logo should be facing you.
8. To minimize discomfort, hold the skin taut surrounding the area you are removing hair from.
9. Gently glide the **Emjoi® Divine** in short, quick, brush like or sweeping strokes in the direction of hair growth.

Note: For your protection, your **Emjoi® Divine** may slow down, or stop operating completely if it is pressed too hard against the skin.

Before removing hair from the bikini line and underarms it is important to use a loofa or exfoliation cream in a warm shower or bath to remove dead skin and prevent ingrown hairs. If it has been an extended amount of time since you have removed hair from your bikini line and underarms, trim the hair with a scissor or trimmer. Make sure to hold your skin taut with one hand while removing hair.

11. The **Emjoi® Divine** is only intended to remove single hairs from the upper lip and chin. Hold area taut and use a small brushing motion. **Do not use like an electric shaver on your entire face!**
12. Repeat within each area until all unwanted hair is removed. The time required to remove unwanted hair depends on the user's hair type.
13. After each use clean your **Emjoi® Divine**.
14. Keep the protective cap on your unit when it is not in use.

Parts Description/Accessories Name




Instructions for use

For ultimate results take a warm bath or shower and use a loofa or exfoliation cream, in small circles to remove dead skin and open pores. Doing this before you use your **Emjoi® Divine** will help to make the hair removal process more comfortable.




Insert plug into base of unit.




Please the adapter into the socket and charge for at least 16 hours, initially. Then charge for 8-16 hours as needed. If your unit is not charged the unit can be used while being plugged in.




Use short, quick, brush like or sweeping motions in the direction of hair growth.



Take extra care to extend the leg before removing hair from behind the knee.



Gently brush the tweezers to remove any hair.



Replace the disc cover.

Warning/important

- Use the **Emjoi® Divine** only for purposes described in this instruction book.
- Children should be supervised to ensure that they do not play with the appliance.
- Please keep these instructions for future reference.
- This unit is intended for one person. We discourage sharing the unit with others.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Warning** - To reduce the risk of burns, fires or electric shock, never leave your **Emjoi® Divine** unattended when plugged in.
- Household use only.
- Do not use an extension cord with this unit.
- Keep the appliance dry.
- This unit is for dry use only.
- Always charge your unit in a cool, dry area.
- Do not place or store the unit in direct sunlight. Please store your unit in a cool dry place at a temperature between 0 - 40°C.
- Do not store your unit where it can fall into a tub or sink of water.
- **Warning** - Do not use your **Emjoi® Divine** while bathing or in the shower. Your **Emjoi® Divine** is not waterproof or water resistant and is not intended to be used near water, in the bathtub or in the shower.
- Do not place your unit in water or drop water into your unit.
- Do not reach for your unit if it has fallen into water. Immediately unplug the unit.
- The **Emjoi® Divine** can be used with the adapter supplied with the unit, after being plugged into an electric outlet or used without the adapter when it is fully charged. Prior to using the unit for the first time cordlessly it needs to be charged for 16 hours.
- When the unit is used with the adapter, place the adapter into the unit and then into the electrical outlet. Make sure that the plug is inserted firmly into the appliance. When you are finished using your unit turn the unit "OFF" and then remove the adapter from the electrical outlet and then from the unit.
- When you unplug your unit please plug on the plug and not on the cord.
- Always unplug your unit when it is not in use, unless it is being recharged, and before cleaning it.
- Do not wrap the cord of your adapter around the unit.
- Keep the cord of the adapter away from hot surfaces.
- Never use your unit if the adapter cord or electrical outlet is damaged.
- Do not cut off the adapter to use it with another plug as this can be a hazardous situation.
- Only use your **Emjoi® Divine** with the adapter supplied with the unit. For questions regarding your adapter in the US contact 1-888-99EMJOI, M-F 9-5 EST.

Changing The Exfoliation Attachment

(Optional Attachment)

1. Make sure that your **Emjoi® Divine** is in the "Off" position.
2. Press the release button on the front of the unit and gently pull off the epilation head.
3. Place the exfoliation attachment into the unit by pressing until it clicks into place.
4. Hold the **Emjoi® Divine** at a 90° angle to the skin. Gently move it against your skin allowing the exfoliation cartridge to smooth away any rough skin.

Using The Exfoliation Attachment

(Optional Attachment)

1. Make sure that your **Emjoi® Divine** is in the "Off" position.
2. Remove the used exfoliation attachment (small cartridge on top of the exfoliation attachment above the plastic head) by holding the exfoliation attachment in one hand and with your other hand gently pull off the exfoliation cartridge.
3. Choose the new exfoliation cartridge you want (Pink for face and Grey for body) and press it into place.

Cleaning The Exfoliation Attachment

(Optional Attachment)

1. It is recommended to clean the exfoliation attachment after each use. Use the cleaning brush, enclosed, to gently brush off any debris or dust from the unit.

Before using your hair remover please read all these instructions carefully and completely.

Optional Attachment

Changing the Optional Attachment: head by pressing the release button shaver head / exfoliation head onto lining up the toothed wheel on the

Turn off the unit. Remove the epilation on the front of the unit. Place the unit until it clicks into place, by body and the attachment.

Warranty

The **Emjoi® Divine** warranty against defects in material and workmanship lasts one year from the date of purchase.

Keep original receipt for warranty service.

During this warranty period, return the product to Emjoi, Inc. with proof of purchase to FDR Station, PO Box 7406, New York, NY 10150. Emjoi will take care of repair, or at their discretion, replacement of a defective unit without charge. For questions regarding this policy you may call toll free 1-888-99-EMJOI (1-888-993-6564).

Important: This warranty does not cover damages resulting from accidents, misuse, alterations, abuse, lack of reasonable care, or performance of services or repairs by an unauthorized service center. The manufacturers and distributors of the **Emjoi® Divine** do not assume responsibility for any damage caused by misuse or use other than that described in these instructions.

Model No. AP-175E
US Patent No. 5,976,157
Other Patents Pending
© Soft Lines International Ltd. 2008

www.emjoi.com

PK-IB-EMJ-175E-010

Rechargeable

Emjoi® Divine



- chance or occurrence of ingrown hairs. After using the epilator you can use body cream or aloe vera to soothe the skin and any possible irritation.
- Using an epilator may cause redness or irritation of the skin. This is a normal reaction that will quickly disappear, but may be longer if you have very sensitive skin or are removing hair from the root for the first few times. If any irritation remains for more than 3 days, discontinue use and consult with your health care provider.
- Sometimes inflammation of the skin can occur when bacteria penetrates the skin. Cleaning the epilation head before and after each use can minimize the risk of infection.
- The **Emjoi® Divine** is only intended to remove single hairs from the upper lip and chin. Hold area taut and use a small brushing motion. **The Emjoi® Divine is NOT an electric shaver and should NOT be used like an electric shaver on your entire face!** Using the **Emjoi® Divine** like an electric shaver, without holding the skin taut, could potentially allow the **Emjoi® Divine** to pinch or grab the skin, which could cause irritation and skin damage.
- Before removing hair from the bikini line and underarms it is important to use a loofa sponge or exfoliation cream in a warm shower or bath to remove dead skin and help minimize the chance or occurrence of ingrown hairs. If it has been an extended amount of time since you have removed hair from your bikini line and underarms (if the hair is longer than 5mm), trim the hair with a scissor or trimmer. Make sure to hold your skin taut with one hand while removing hair. Some women may experience irritation after removing hair from the underarms and bikini line for the first time. We suggest testing the unit on a small part of the skin in these areas first.
- To preserve and extend the life of your battery it is recommended to occasionally discharge the battery, let the charge run out completely, then recharge it.
- This appliance must be disconnected from the supply mains when removing the battery.
- The battery must be removed from the appliance before it is scrapped.
- The battery is to be disposed of safely.
- Do not continually rub the unit on the same area or apply strong pressure.
- Keep the protective cap on your unit when it is not in use.

Frequently asked questions

- Q: Does the **Emjoi® Divine** hurt?
- A: The first time you use the **Emjoi® Divine** you might feel a prickling sensation, this feeling is due to the fact that you are removing hair from the root. After several uses, the tweezing becomes more comfortable even for those with sensitive skin.
- Q: How should I hold the **Emjoi® Divine**?
- A: To minimize discomfort, hold the skin surrounding the area you are removing hair from taut. Gently glide, do not apply pressure, the **Emjoi® Divine** in short, quick, brush like or sweeping strokes in the direction of hair growth.
- Note:** For your protection, your **Emjoi® Divine** may slow down, or

- stop operating completely if it is pressed too hard against the skin.
- Q: Do I have to use my **Emjoi® Divine** with the adapter?
- A: No. Since you have the rechargeable **Emjoi® Divine** you can use it with the adapter plugged into an electrical outlet or you can charge your unit and use it without the cord.
- Q: How long should I charge my **Emjoi® Divine** if I want to use it without the cord?
- A: Initially, you need to charge your unit for 16 hours, like you would for a cell phone. Once your unit has been initially charged, you will be able to recharge it for 4-6 hours when needed. To extend the lifetime of your unit we recommend that you fully drain, let the battery wear out, every six months.
- Q: Can I use the **Emjoi® Divine** on my upper lip?
- A: Yes, the **Emjoi® Divine** is perfect for removing **individual** hairs from the upper lip.
- Important:** Hold your upper lip taut and use short brushing strokes to remove individual hairs from your upper lip.
- Q: Can I use the **Emjoi® Divine** anywhere on my face?
- A: No. The **Emjoi® Divine** is only intended to remove individual hairs from the upper lip and chin area. When removing hair from your upper lip and chin, hold your skin taut and use short brushing motions. **Do not use Emjoi® Divine** like you would for an electric shaver on your entire face.
- Q: Can I use the **Emjoi® Divine** on my bikini line and underarm?
- A: Yes. Before removing hair from the bikini line or underarms it is important to use a loofa sponge in a warm shower or bath to remove dead skin and prevent ingrown hairs. Since these areas can be sensitive, it is important to hold the skin taut.
- Q: Will my hair grow back as fast as it does when I shave?
- A: No. With shaving you are cutting the hair at the surface, so hair grows back quickly. When you use the **Emjoi® Divine** it removes hair from the root so it takes longer, up to 4-6 weeks, to grow back.
- Q: What if my skin becomes red after using the **Emjoi® Divine**?
- A: Whenever you remove hair from the root your skin may become red or irritated. To soothe irritation you can use lotion with aloe vera or antibiotic ointment.
- Q: What can I do for ingrown hairs?
- A: We recommend using a loofa or an exfoliation cream in the shower or bath to soften the skin and any ingrown hairs, enabling the **Emjoi® Divine** to remove the hair from the root. If any irritation remains for more than 3 days, discontinue use and consult with your health care provider.
- Q: I have varicose veins, can I use the **Emjoi® Divine**?
- A: Regarding any medical issues or questions, we strongly advise you to consult with your health care provider prior to use.
- Q: Why is the **Emjoi® Divine** curved?
- A: Because your body is curved. The tweezing head is curved to gently and effectively glide along the contours of your body.